



Asphalt Overlay with Geotextile Fabric

- 1. Cut a heel and/or mill along the perimeter of areas to be resurfaced, so new asphalt will tie in flush with existing pavements.
- 2. Clean areas to be resurfaced.
- 3. Apply liquid asphalt cement (AC-20) at a rate of .25 gallons per square yard.
- 4. Install Geotextile Fabric membrane as proposed.
- 5. Install asphalt overlay at proposed thickness using self-propelled paving machine and compact to maximum density.