




ASPHALT AND CONCRETE • GENERAL CONTRACTORS



## *Concrete Sidewalk Repairs*

1. Identify and mark areas of repair.
2. Saw cut or jackhammer the perimeter of each area.
3. Excavate and dispose of existing concrete down to subbase.
4. Recompact subbase material. Add new subbase material if necessary.
5. Set forms and pour new 3500 P.S.I. concrete to the proposed thickness.
6. Finish concrete to new or existing grades, score joints and broom finish.
7. Once concrete has set up, forms will be removed and back fill with existing soils.